FARROW& BALL®

CRAFTSMEN IN PAINT AND PAPER

PRODUCT ADVICE SHEET

Full Gloss

All Farrow & Ball paints are eco friendly with low or minimal VOC (Volatile Organic Compounds) content and are water based giving them a low odour and quick drying time which benefits both you and the environment.

Available Tin Sizes: ,750 ml,2.5 L,,

In all Farrow & Ball colours. Available direct from Farrow & Ball (visit www.farrow-ball.com, email: sales@farrow-ball.com or call: +44 (0) 1202 876141), our Showrooms and selected stockists internationally.

Product Overview:

Noted as the glossiest water based finish on the market, Full Gloss has a wonderfully reflective 95% sheen that makes a dramatic statement. Resistant to water, flaking, peeling and colour fade for up to six years, its high durability makes it perfect for wood and metal both inside and out. Washable & wipeable. Not suitable for use on plastic. Not suitable for exterior decking or other pressure treated wood.

Recommended Primer & Undercoats:

For use on interior woodwork : Farrow & Ball Interior Wood Primer & Undercoat

For use on exterior woodwork : Farrow & Ball Exterior Wood Primer & Undercoat

For use on metal : Farrow & Ball Metal Primer & Undercoat

For use on interior walls & ceilings : Farrow & Ball Wall & Ceiling Primer & Undercoat

Knotty or Resinous Wood Preparation:

Heat the knot to draw out any excess resin (we recommend using a hot air paint stripper). Scrape off any residue resin, and then thoroughly clean the area with white or methylated spirit. Allow the area to dry thoroughly before continuing.

New and Unpainted Interior Wood (Not Floors) Preparation:

Ensure all surfaces are sound, clean, dry and free from dirt, grease and other contamination. Fill any cracks, holes and open joints with an appropriate filler. To improve the paint's adhesion, lightly sand the surface. Prepare any filled, knotty or resinous areas as above and patch prime with Farrow & Ball Wood Knot & Resin Blocking Primer. Apply a diluted coat of Farrow & Ball Interior Wood Primer & Undercoat (20 % water) in the correct colour tone for your top coat, followed by one full (undiluted) coat. Allow a minimum of 4 hours drying time between coats. Apply two coats of your chosen Farrow & Ball finish, allowing the correct drying time between coats.

Previously Painted Interior Wood (Not Floors) Preparation:

Ensure all surfaces are sound, clean, dry and free from dirt, grease and other contamination. Remove any areas of old paint which are peeling or blistering as flaking or peeling can occur if you paint over weak paint layers. Blend and 'feather' the edges of areas of old paint, as this helps to smooth out the surface. Fill any cracks, holes and open joints with an appropriate filler. Lightly sand the surface to improve paint adhesion. Patch prime any filled or bare knotty / resinous areas with Farrow & Ball Wood Knot & Resin Blocking Primer. Apply one coat of Farrow & Ball Interior Wood Primer & Undercoat, in the correct colour tone for your top coat (and allowing a minimum of 4 hours drying time between coats). Then apply two coats of your chosen Farrow & Ball finish, allowing the correct drying time between coats.

Interior MDF Preparation:

Where possible always aim to use high quality MDF, as higher quality MDF tends not to suffer from raised fibres and so will not require surface sanding. Lower quality MDF may contain less tightly bound fibres, which may become raised as paint is applied. If the fibres do become raised, lightly sand the surface between coats to ensure a smooth finish. Lightly sand the edges of the MDF to provide a sound surface and to reduce paint absorption. Apply one coat of Farrow & Ball Wood Floor Primer & Undercoat, in the correct colour tone for your top coat and allowing a minimum of 4 hours drying time between coats. Apply two coats of your chosen Farrow & Ball finish, allowing the correct drying time between coats.

Ferrous Metal Preparation:

Thoroughly clean and degrease new and previously painted metal surfaces. Remove any weak paint and rust back to bare metal. Apply two coats of Farrow & Ball Metal Primer & Undercoat, in the correct colour tone for your top coat, and allow a minimum of 4 hours drying time between coats. Apply two coats of your chosen Farrow & Ball finish, allowing the correct drying time between coats. Cast Iron: We recommend that a specialist primer is applied to Cast Iron surfaces prior to painting as water-based primers may lead to flash rusting.

Non Ferrous Metal Preparation:

Thoroughly clean and degrease new and previously painted metal surfaces. Remove any weak paint and lightly sand surface to improve adhesion of your primer & undercoat. Apply two coats of Farrow & Ball Metal Primer & Undercoat, in the correct colour tone for your top coat, and allow a minimum of 4 hours drying time. Apply two coats of your chosen Farrow & Ball finish, allowing the correct drying time between coats.

Galvanised Metal Preparation:

Treat all surfaces with an Etch Primer or Mordant Solution, ensuring any excess product is removed before you begin painting. Apply two coats of Farrow & Ball Metal Primer & Undercoat, in the correct colour tone for your top coat, and allow a minimum of 4 hours drying time. Apply two coats of your chosen Farrow & Ball finish, allowing the correct drying time between coats.

Radiator Preparation:

This product is suitable for painting conventional hot water filled radiators where the surface temperature does not exceed 60° C. We do not recommend using this product to paint steam filled radiators which operate at a much higher temperature. Ensure the radiator is turned off and has cooled before you begin painting it. Thoroughly clean and degrease new or previously painted radiator surfaces. Remove any weak paint and rust back to the original surface. Apply two coats of Farrow & Ball Metal Primer & Undercoat, in the correct colour tone for your top coat and allowing a minimum of 4 hours drying time between coats. Apply two coats of your chosen Farrow & Ball finish, allowing the correct drying time between coats. Cast Iron Radiators: We recommend that a specialist primer is applied to Cast Iron surfaces prior to painting as water-based primers may lead to flash rusting.

Exterior Bare Wood Surface Preparation:

Ensure surfaces are sound, clean, dry and free from dirt, grease and other contamination. Fill any cracks, holes and open joins with a water based exterior wood filler. To improve the paint's adhesion, lightly sand the surface. In environments where wood rotting fungi is likely to occur, treat with exterior wood preservative prior to priming. Prepare any knotty or resinous areas as above and patch prime with Farrow & Ball Wood Knot & Resin Blocking Primer. Apply one coat of Farrow & Ball Exterior Wood Primer & Undercoat, in the correct colour tone for your top coat, and allow a minimum of 4 hours drying time. Apply two coats of your chosen Farrow & Ball finish, allowing the correct drying time between coats. Please note: Repeatedly repairing cracks, holes and open joints in a surface may indicate that the surface is nearing the end of its life and will require additional effort to maintain it. If this is the case consider renewal or replacement.

Exterior Previously Painted Wood Surface Preparation:

Ensure all surfaces are sound, clean, dry and free from dirt, grease and other contamination. Remove any areas of old paint which are peeling or blistering as flaking or peeling can occur if you paint over weak paint layers. Blend and 'feather' the edges of areas of old paint, as this helps to smooth out the surface. Fill any cracks, holes and open joints with a water based exterior wood filler. Lightly sand the surface to improve paint adhesion. In environments where wood rotting fungi is likely to occur, treat with exterior wood preservative prior to priming. Prepare any knotty or resinous areas as above and patch prime with Farrow & Ball Wood Knot & Resin Blocking Primer. Apply one coat of Farrow & Ball Exterior Wood Primer & Undercoat, in the correct colour tone for your top coat (and allowing a minimum of 4 hours drying time between coats). Then apply two coats of your chosen Farrow & Ball finish, allowing the correct drying time between coats. Please note: Repeatedly repairing cracks, holes and open joints in a surface may indicate that the surface is nearing the end of its life and will require additional effort to maintain it. If this is the case consider renewal or replacement.

New or Unpainted Plaster/Dry Lined Surfaces (Modern Construction) Preparation:

If your plaster is new non powdery and sound you can simply apply a diluted coat of your chosen Farrow & Ball colour. Please note: British Standard 6150:2006 recommends a typical drying time for new plaster of 7 days for every 5mm thickness.

Suggested Maximum Dilution Rates:

Bare dry skim plaster/dry lined walls, bare dry plaster board, patch filled plaster = up to 20% water. NB: The dilution rate will depend on the porosity of the surface. We recommend you test the level of dilution on a patch to determine the level of dilution required. Dilute the top coat (of your chosen colour) with water and apply as a "mist" coat. Please note: When porous plasters are not sufficiently prepared, difficulties in application, variation in sheen or uneven colour may occur.

Previously Painted Walls Preparation:

Apply one coat of Farrow & Ball Wall & Ceiling Primer & Undercoat, in the correct colour tone for your top coat (and allowing a minimum of 4 hours drying time between coats). Then follow with two coats of your chosen colour to promote adhesion and full colour depth.

Painting Lining Wallpaper:

For unpainted Lining Paper apply one coat of diluted Farrow & Ball Wall & Ceiling Primer & Undercoat (maximum 15% water), in the correct colour tone for your top coat (see dilution details below) before applying two full coats of your chosen colour. NB: The dilution rate will depend on the porosity of the surface. We recommend you test the level of dilution on a patch to determine the level of dilution required. If you do not want to apply a primer and undercoat, as an alternative, you can dilute the top coat with approximately 10% water and apply as a "mist" coat. Please note: When porous papers are not sufficiently prepared, difficulties in application, variation in sheen or uneven colour may occur.

Using Interior Caulks & Sealants:

Where small gaps and cracks require filling or sealing, best results are achieved with an acrylic based decorators' caulk which is a water-based, flexible filler. Use the minimum of caulk necessary as a smaller bead will dry quicker and will be less prone to cracking. Follow the manufacturer's application instructions and drying times (typically 2 - 3 hours) before applying your chosen Farrow & Ball finish. Estate Eggshell, Full Gloss and Dead Flat - 2 coats may be applied directly (allowing a minimum of 4 hours drying time between coats). Estate Emulsion and Modern Emulsion – Apply an undiluted coat of Wall & Ceiling Primer & Undercoat in the correct colour tone for your top coat (allowing a minimum of 4 hours drying time between coats).

Painting Over Interior Wall Fillers

For best results always use a filler which has the same porosity and density as the surface which is being repaired. Fillers which have a different porosity or density may lead to visible differences in colour or tone. Follow the filler manufacturer's application instructions and drying times then apply a diluted coat (20 – 25%) of Farrow & Ball Wall & Ceiling Primer & Undercoat in the correct colour tone for your top coat (and allowing a minimum of 4 hours drying time between coats). Then follow with two coats of your chosen colour to promote adhesion and full colour depth. This product may not be compatible with highly alkaline/cement-based fillers. Please note that this product may not be compatible with sand-based filler. Wherever possible, we recommend using an alternative type of filler. However, if no alternative is available, ensure the filler is adequately sanded and free of all dust and contaminants before proceeding with the steps outlined above.

Painting Over Interior Wood Fillers:

Follow the filler manufacturer's application instructions and drying times and patch prime with Farrow & Ball Wood Knot & Resin Blocking Primer. Apply a coat of Farrow & Ball Interior Wood Primer & Undercoat in the correct colour tone for your top coat. Allow a minimum of 4 hours drying time between coats. Apply two coats of your chosen Farrow & Ball finish, allowing the correct drying time between coats.

Painting Over Exterior Wood Fillers:

Follow the filler manufacturer's application instructions and drying times and patch prime with Farrow & Ball Wood Knot & Resin Blocking Primer. Apply a coat of Farrow & Ball exterior Wood Primer & Undercoat in the correct colour tone for your top coat. Allow a minimum of 4 hours drying time between coats. Apply two coats of your chosen Farrow & Ball finish, allowing the correct drying time between coats.

If replacement putty is required for new or existing glazing, for best results use an acrylic based glazing putty which is designed to work well with modern water based paints and primers. Bare wood must first be primed with an undiluted coat of Farrow & Ball Exterior Wood Primer & Undercoat, including the end grain, and allowed to dry for a minimum of 4 hours before applying the glazing putty. Apply the glazing putty following the manufacturer's application instructions and drying times before applying your chosen Farrow & Ball finish as follows: Exterior Eggshell and Full Gloss – Apply an undiluted coat of Farrow & Ball Exterior Wood Primer & Undercoat in the correct colour tone for your top coat (allowing a minimum of 4 hours drying time between coats) followed by 2 coats of your chosen top coat (once again allowing a minimum of 4 hours drying time between coats). Ensure the glass is thoroughly clean and overlap the final top coat onto the glass by approximately 1mm to achieve a seal.

Painting Interior Brickwork:

Interior brickwork must be completely dry and free of damp before painting. Interior brickwork which is powdery, flaky or unstable should first be patch primed using one coat of Farrow & Ball Masonry & Plaster Stabilising Primer. The following Farrow & Ball finishes may be applied to interior brickwork: For Full Gloss, Estate Eggshell and Exterior Eggshell – Apply an undiluted coat of Farrow & Ball Interior Wood Primer & Undercoat in the correct colour tone for your top coat (and allowing a minimum of 4 hours drying time between coats) followed by 2 coats of your chosen top coat (once again allowing a minimum of 4 hours drying time between coats). For Exterior Masonry – apply 2 coats directly, allowing a minimum of 5 hours drying time between coats. Do not use Farrow & Ball Masonry & Plaster Stabilising Primer as a general primer on sound brick surfaces.

Waxed or Highly Polished Surface Preparation:

If you are painting onto previously waxed or highly polished surfaces, you will need to remove the existing coating of treatment by sanding back prior to painting. We recommend testing a small area as Farrow & Ball paints may not be compatible with some waxes and polishes.

How to Apply Paint to Walls by Brush:

Stir thoroughly before use. Ensure all surfaces are sound, clean, dry and free from dirt, grease and other contamination. Please note that flaking or peeling may occur if you paint over weak paint layers – to avoid this sand back any previous weak paint layers before you start painting. Where required apply Farrow & Ball Wall & Ceiling Primer & Undercoat to improve paint adhesion and promote depth of colour. Using a fine-tipped synthetic bristled brush, apply the paint in a vertical direction then spread the paint out evenly in a horizontal direction. On application of the final coat lay off the paint in a single direction to ensure that any brush marks and brush patterning effects (sometimes visible in certain lighting conditions) are minimised.

Painting Terracotta:

The following Farrow & Ball finishes may be applied to terracotta: Exterior Masonry, Full Gloss and Exterior Eggshell – 2 coats may be applied directly (allowing a minimum of 4 hours drying time between coats).

How to Apply Paint to Walls by Roller:

We do not recommend applying Full Gloss by roller to large areas such as walls and ceilings as a decrease in sheen level and a slight surface texture (stippling) may be visible.

How to Apply Paint to Trim by Brush:

Stir thoroughly before use. By 'trim' we mean: skirting boards, picture rails, dado rails, doors, door frames and architraves, interior window sills and window frames (providing they aren't plastic). Farrow & Ball paints are water borne, and unlike solvent borne paints, water borne paint is more resistant to sagging and you will achieve the best finish by painting a thicker coat. For best results use a quality fine-tipped synthetic bristled paint brush (e.g. Farrow & Ball Paint Brush). Load the brush well and apply a generous first coat. Brushing first in a vertical direction then in a horizontal direction until an even coating has been applied. Finish by 'laying off' the paint in one direction using light pressure, with the brush held at an angle of approximately 30°. Do not "overwork" the paint or attempt to brush it out in thin even coats as you would a traditional solvent borne paint as this may create excess brush marks. Allow to dry completely (for a minimum of 4 hours) before applying a second coat following the same technique as before.

Stir thoroughly before use. By 'trim' we mean: skirting boards, picture rails, dado rails, doors, door frames and architraves, interior window sills and window frames (providing they aren't plastic). This paint finish can also be applied using a Medium Pile Woven Polyester Roller. This will provide a good finish with minimal stippling and is a quick method of application. However, where an optimum finish is required, we would recommend brush application using a Farrow & Ball fine-tipped, synthetic bristled brush.

Advice for Repairing Damage and Touching In:

If your paintwork becomes damaged or marked you may need to repaint. To achieve the best results we recommend applying a single coat of paint over the entire wall or walls that have the damage, using the same batch of paint you originally carried the work out with. This best practice will avoid any noticeable variation in colour or finish. If you do chose to touch-in to repair damage, the following recommendations will help you achieve the optimum finish. 1. Always aim to use the same batch of paint. If you use a different batch, although we control colour to tight specifications, you may observe slight colour

and sheen variations. If you are unable to use the same batch of paint we recommend that you apply a single coat of a different paint batch to an entire wall as any slight variations will be much less noticeable when observing from wall to wall.

2. Always use the same preparation techniques when you make any repairs as you used when you originally painted the wall. It may not always be possible to achieve a perfectly consistent finish – if for example you have used filler which has a different texture and absorbency to the rest of the wall, this may cause a slightly patchy finish.

3. Always use the same application tool and method as when you originally painted this wall. Ensure that the edges of the touched in paint are blended in "feathered" to make the transition between old and new paint areas less noticeable.

4. Over time the colour of the paint, whether on the wall or in the tin, may slightly alter. Therefore the newer the paintwork is, the better the finish you will achieve by touching-in.

Please note that when touching in the darker the colour and higher the sheen the more difficult it will be to achieve a uniform finish compared to lighter coloured, lower sheen paints.

Spray Settings:

Airless Spraying – Good results can be achieved by the set up of 15 thou (381μ m) 65° angle tip or 18 thou (457μ m) 65° angle tip using a pressure of between 2300 – 2700 psi (159 - 186 bar). HVLP Spraying – Depending on the apparatus used, the paint may need to be diluted with water by up to 30%. Experiment with air control valve, material flow adjustment, fan size and spray pattern settings on a piece of cardboard or an inconspicuous area until a satisfactory finish is achieved. Apply several thin coats, allowing each coat to dry fully before applying the next one.

Over Coating Pale Colours with Dark Colours:

Changing the shade of exterior woodwork from light to dark will greatly increase the amount of heat the surface is able to absorb from the sun. In some cases, this additional heat may cause resin and gases to be released by the wood, particularly from any knots. This can result in peeling and blistering, which may not have occurred when painting the same surface with a lighter shade. To minimise the risk of this happening, and to achieve a long-lasting finish, we recommend removing as much of the previous coating as possible to expose any knots and resinous areas so that they can be prepared as above, before patch priming with Farrow & Ball Wood Knot & Resin Blocking Primer. This should be followed with a coat of the Farrow & Ball Exterior Wood Primer & Undercoat in the correct tone for your new paint colour, and then by your topcoat.

Other Product Applications:

If you wish to use Farrow & Ball products for any applications which are not featured here, please contact Customer Services for advice on +44 (0) 1202 876141 or email customer.services@farrow-ball.com. Please note that calls may be recorded for training purposes.

Application Information:

Do not paint in temperatures below 10°C or in excessive heat above 30°C. Avoid painting in direct sunlight. Avoid applying outdoors if there is a likelihood of rain. For best results apply early in the day, allowing the product time to dry before the evening (when condensation can occur).

Coverage Rate (m2/l per coat): : Up to 12

Drying Time: : Dry in 2 hours.

Typical Recoat Time: : Recoat after 4 hours

Curing Time: : Please note that some darker paint colours will take up to 14 days to achieve full hardness, strength and durability.

Sheen Level: : 95% Recommended Number of Coats: : 2*

Darker/stronger colours may require additional coats. Please note: The drying and Recoat times provided are bas rying times may be longer in cooler and/or higher humidity environments. Darker colours may take longer to dr oplying over solvent based coatings.	
Density: : 1.2 - 1.4 g/cc	
Vet Film Thickness: : $80 - 120 \ \mu m$	
pplication Humidity: : < 80 % RH	
Vet Abrasion Class: : 1	
ubstrate Moisture Content:	
laster Walls & Ceilings = $< 0.5 \%$: Interior Wood = $< 15 \%$	
xterior Wood = $< 15\%$: Interior Brick = $< 1\%$	
Vater Vapour Permeability according to DIN EN ISO 7783 2 (sd [m]):	
.767 (Class III, limit >1.4). This is the resistance of the paint film to water vapour expressed as the equivalent thic alue the more breathable the paint film. Paint breathability is class rated, from Class I to Class III. Class III in this	
Colour Accuracy:	
Check for colour accuracy prior to use as Farrow & Ball will not be liable for decorating costs caused as a result of nore than one tin of the same colour is to be used ensure that batch numbers are identical or intermix before use.	
Vater Contact:	
o extend the service life of this finish, standing surface water should not be allowed to pool on horizontal surface	·S.
Cleaning:	
ull Gloss is washable, wipeable and stain resistant. Wipe gently with a soft damp cloth or sponge.	
Clean Up:	
Lemove as much product as possible from brushes or rollers. Clean brushes / rollers with warm soapy water.	
torage Advice:	
his product is water based and must be protected from frost and extreme temperatures. Use within 6 months of p eterioration of contents or packaging after this date.	purchase. We accept no responsibility for th
formulation:	
water based paint made using a traditional alkyd binder.	
Environmental & Disposal Advice:	
o not empty into drains or watercourses. Dispose of contents/container to waste disposal site in accordance with	local/national regulations. Contact the local
nvironmental Department for disposal instructions. Metal containers may be recycled.	
OC Content Information:	
U limit value for this product (cat. A/[d]): 130g/l (2010). This product contains max 13g/l VOC.	
ead Advice:	
pecial precautions should be taken during the preparation of old paint surfaces (especially those from pre-1970), a dvice and guidance see coatings.org.uk/paintsafe.	s they may contain harmful lead. For furthe

Health & Safety Advice:

Keep out of reach of children. Ensure good ventilation during application and drying. Do not get in eyes, on skin, or on clothing. If medical advice is needed, have product container or label at hand. IF ON SKIN: Wash with plenty of soap and water. Do not use solvent thinners or White Spirit. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. IF SWALLOWED: Call a doctor if you feel unwell. Safety data sheet available on request.

Contact Us:

For advice on colours, paint finishes or wallpaper our customer services team is on hand to help you, just call +44 (0) 1202 876141, email sales@farrowball.com, or write to us at Farrow & Ball, Uddens Estate, Wimborne, Dorset, BH21 7NL, UK. Please note that calls may be recorded for training purposes. Imported in EU by Farrow & Ball, Kaiserstraße 25, Frankfurt am Main, Deutschland, +49 (0) 69 2424 6269.

Disclaimer:

The information given in these specification sheets and technical advice - whether verbal, in writing or by way of trials - is for guidance and is given in good faith but without warranty, since skill of application and site conditions are beyond our control. For further information please contact our Customer Services Department. We can accept no liability for the performance of the products arising out of such use, beyond the value of the goods delivered by us. This does not affect your statutory rights.

ssue Date: 12/12/2019